


SPARE PARTS LIST

Product	BACK MOUNTED ROTARY	
Model	256 / 258	
Nr.	9519 (F810) / 9521 (F760)	
Date	01/2005	Page.: 1



Spare parts list

Ref.	Part Number	Description	Qty	Ref.	Part Number	Description	Qty
1	03100	Body	1	71		Washer 8mm	1
2	03101	Housing	1	72	01047	Pin	1
3	01175	Moving fork	1	73	03103	PTO pulley F6 'Ø 133/140 (2-speed)	1
4	01176	Locking fork	1		07750	PTO pulley F810 (1-speed) ø137mm	1
5	01173	Axle	1	74		Screw hex M8	1
6	01174	Locking Handle	1	75		Lockwasher 8mm	1
7		Screw hex M10x20	4	76	03105	V-belt F6 (BX50)	1
8		Lockwasher 10 mm	4		03138	V-belt F8 (LB52)	2
9		Screw hex M10	4	77	03110	Cover belt F6	1
10		Numberplate	1		03139	Cover belt F8	1
11	03106	Tensioner idler support	1	78	01178	Right double tine	1
12	03107	Distance piece	1	79	01182	Right single tine	1
13	03108	Distance piece	1	80	01179	Left double tine	1
14		Screw hex M12x65	1	81	01183	Left single tine	1
15		Screw hex M12	1	82	01197	Clip pin 10x40	4
16	01091	Tensioner idler	2	83	01123	Left side blade	*)
	07752	Tensioner idler F810 (1-speed)	1	84	01124	Right side blade	*)
17	01092	Torsion spring	1				
18		Roll pin 6x20 mm	1			<i>Option</i>	
19	03111	Main cover	1	85		<i>Screw hex M8x25</i>	
20	03112	Fixing plate	2	86	01200	<i>Wheel support</i>	1
21		Screw hex M8x16	10	87	01199	<i>Spindle axis</i>	1
22		Screw hex M8x20	4	88	03145	<i>Washer 25x32x2,5</i>	1
23		Nut M8	14	89	03146	<i>Distance piece</i>	1
24		BorgNut M8	2	90		<i>Screw hex M12x80</i>	1
25		Butterflynut M8	2	91		<i>Nut M12</i>	1
26		Washer 8mm	12	92		<i>Split pin 3,2x40</i>	1
27		Washer 8mm	2	93	01022	<i>Clip pin 10x42</i>	1
28		Lockwasher 8mm	16	94		<i>Washer 12mm</i>	1
29	03113	Left external cover	1	95	01201	<i>Wheel RN160</i>	1
30	03114	Right external cover	1				
31	03115	Left moving side	1	96		Screw hex M8x70	3
32	03116	Right moving side	1	97		Screw hex M8x65	1
33		Screw hex M6x10	2	98		Washer 8mm	3
34		Nut M6	2	99		Lockwasher 8mm	3
35	03117	Main flap	1	100		Nut M8	4
36	03118	External flap	2	101	03148	Distance piece	4
37		Screw hex M8x16	4	102		Screw hex M6x12	12
38		Washer 8mm	4	103		Nut M6	12
39		Lockwasher 8mm	4	104	03149	Right transmission cover	1
40		Nut 8mm	4	105	03150	Left transmission cover	1
41	03119	Lever depth adjust	1	106	03151	Sprocket shaft	1
42	03120	Articulated support	1	107	03152	Rotary axle	1
43	03121	Plastic cap	1	108	03153	Protection washer 31x47x1,2 mm	2
44		Screw hex M8x70	1	109	03154	Joint 30x47x7 mm	2
45		Locknut M8	1	110	01132	Special washer 37x58x1 mm	2
46		Washer 8mm	1	111	01130	Bearing 6206	2
47	03122	Fixing plate	2	112	01131	Circlip 30mm	2
48	03123	Heel	1	113	01896	Bearing 6204	1
49		Screw hex M8x25	2	114	01256	Bearing 6205-2 RS	1
50		Screw hex M6x20	2	115	01192	Drive chain 15,8/61	1
51		Nut M6	2	116	01128	Joint transmission cover	1
52	03124	Clip pin 8x27	1				
53	03125	Stationary cam	1				
54	01118	Handle	1				
55	01119	Plastic cap	1				
56		Screw hex M8x25	2			*) Blades required:	
57		Washer 8mm	1			F600/610/660/720:	
58		Lockwasher 8mm	2			10x Nr. 01123 / 10x Nr. 01124	
59	03128	Clutch fork	1				
60	03129	Clutch spring	2			F800/F810:	
61	03130	Washer 20 mm	1			12x Nr. 01123 / 12x Nr. 01124	
62		Washer 8mm	2				
63	03131	Flange bushing	2				
64	03132	Driven pulley F660/F720 ø147mm (2-speed)	1				
	07751	Driven pulley F810 (1 speed)	1				
65	03133	Sliding collar	1				
66	03134	Clutch cover	1				
67		Screw hex M6x12	5				
68		Nut M6	5				
69		Butterflynut M8	1				
70	03127	Safetyrod F6/7	1				
	03135	Safetyrod F8	1				